DT292

This Quick Reference Guide describes the MD Evolution services available with the DECT terminal DT292.

Switching On/Off

Switch on:	NO (until display lights up)
Switch off:	NO (until display is blank)

Answer calls

Answer:	YES
Mute ringing:	C/MUTE + Ring off icon
Call pick-up	13 + no of ringing extension + YES
Call pick-up within a group	14 + YES
Call pick-up on general bell	15 + YES

Make calls

Internal/ external calls:	Extension no or Line access code + External no + YES
Last External No Redial:	11 + YES
Abbreviated Number:	Abbreviated No. + YES
Dial number from call list:	YES short + ◖◗ Select number + YES
Make a call from Phonebook	Menu: PhoneBook>Find&Call + press the key with first letter of name + YES + ◖ Scroll down to select name+ YES

You get busy tone or no answer

Automatic Callback:	1+ NO. Go off hook when called back
Intrusion:	3

During an ongoing conversation

Hands-free speaking:	(Toggle on/ off)
Mute microphone:	+ Ring off icon (Toggle on/ off)
Inquiry	R + Number of 3rd party
Refer back (Switch between calls):	2
Conference:	R + Number of 3rd party + 3
Transfer a call:	R + Number of 3rd party + NO (Before or after answer)
Answer a camp-on call	After the beep, 1+ 14
End call:	NO + Display of call duration

Call forwarding

Cancel any call forwarding	6 0 + YES
Immediate call forward	6 1 + internal/external no + YES
Call forward on no answer	6 2 + internal/external no + YES
Call forward on busy	6 3 + internal/external no + YES
Call forward on no answer or busy	6 9 + internal/external no + YES
Do not disturb	6 4 + YES
Follow-me	6 5 + your extension no + password + YES
Call forward to another internal/external number	6 5 + * + your extension no + receiving no + password+ YES

Your voice mail

Notification of new voice messages	Icon of notification is displayed.
Call your mailbox from your extension	Voicemail number + your password + YES. We recommend to program this voicemail nb on the Message key. Default no 884.

Other services

	Activation	Cancellation
Appointment reminder	7 1 + HHMM 4 digits + YES (HHMM hour+minutes)	7 1 + 9 + YES
Retrieve from a group	6 8 + YES	6 8 + YES
Temporary operator	6 7 + YES	6 7 + YES
Lock your phone	7 8 + YES	7 8 + password + YES
Key Lock	Menu: Settings> AutoKeyLock + YES + select with ◖◗ + YES	
Key unblock	◖ + YES	
Change your password	7 9 + old password + new password+ YES. Default value: 1234. We recommend to change this default password.	
Vibrating Alert	Menu: Settings> Alerts> Vibrator + YES + ◖◗ select option + YES	

Phonebook

100 entries (name up to 12 characters+number up to 24 digits).

Add name and number	Menu: PhoneBook>Store>AddNew + YES + Enter name + YES + Enter number + YES
Change a name or a number	Menu: PhoneBook>Find&Edit>Edit+ YES + enter first letter + YES + ◖ scroll down + YES (twice for number) + correct name/number + YES + YES
Delete a name or a number	Menu: PhoneBook>DeleteAll+ YES + enter first letter + YES + ◖ scroll down + YES
Add numbers from CallList	Menu: PhoneBook>Store>AddCallList + YES + ◖◗ + YES + enter name+ YES + edit the number + YES

Menu structure

Press ◐◑ to access the on-hook menu when in stand-by mode or to access the off-hook menu during a call. Navigation keys in the Menu:

◐◑ Move within the menu

(YES 📞) Make selection and move in the submenu.

(◀ NO) Move to the previous menu.

(C/MUTE) Move to the idle display.

Phonebook	
Find&Call	
Store……………...……	AddNew, AddCallList
Find&Edit………………	Edit, Delete
DeleteAll	
Settings	
Alarm*…....……………	SetAlarm, AlarmOff
AutoKeyLock	
Alerts……….…...……	RingVolume
	RingType…….Internal, External, Callback, Message
	KeySound
	DiscreetRng
	Vibrator………...OnIfSilent, On, Off
PhoneLock……………	PowerOn, Subscript, Change PIN
MasterReset	
Language	
MessageKey…………	MessageKeyNo
Display……	………..…… Light, Contrast
Information	
CallList*	
MissedCalls*	
LastCall*	
TotalCalls	
ShowIPEI	

* Available under certain circumstances

Enter letters of the name

Press 1/2/…times the digit key as required. Example : 7777 to enter letter S or 6 to enter letter M. See below table. Press YES when the name is complete.

Phone key	Number of times to press the key												
	1	2	3	4	5	6	7	8	9	10	11	12	13
1	-	?	!		.	:	'	"	,	(	)		1
2	A	B	C	À	Ä	Æ	Á	Å	Â	Ç	2		
3	D	E	F	É	Ê	È	Ë	3					
4	G	H	I	Í	Ì	Î	Ï	4					
5	J	K	L	5									
6	M	N	O	Ñ	Ö	Ø	Ó	Ò	Ô	Õ	6		
7	P	Q	R	S	ß	7							
8	T	U	V	Ù	Û	Ú	Ü	8					
9	W	X	Y	Z	Ý	9							
0	Space	+	&	@	/	$	%	£	€	\	±	½	0
#			<	●	>	^	_	°	µ	¿	¡	§	

Control keys.

◐◑ to shift left or right

* to switch from upper to lower case. A long hit activates or de-activates the tone sending.
1 to enter a space
C/Mute to change a wrong entry. A long hit deletes the whole entry.

Description of DT292

1. Volume Up. Off-hook: raise earpiece volume.
2. Volume Down. Off-hook: lower earpiece volume.
3. Off-hook / Yes. Answer call, accept.
4. Clear (C) / Mute. Delete latest entered digit. Backspace when editing text. Cancel a menu option. Microphone, ringer and warning on/off.
5. Control key (up). Scroll up through menus or name list. Move left through the choices.
6. 1 / Space. Space when editing text
7. Battery (rear side)
8. Star / Pause / Text case. Insert a dial tone pause. Upper/lower case in text mode.
9. Microphone
10. Warning light. Ringing, message waiting, battery low, exit cover area.
11. Earpiece. Please note: *The phone may retain small magnetic articles around the earpiece region.*
12. Display (3 rows). Display at rest. Work is the network name and 4711 is (your) extension number.
13. On/Off / On-hook / No. Switch on/off, end call, one menu back. Cancel a menu option.
14. Control key (down). Scroll down through menus, name list. Move right in choices.
15. Keypad

16. Hands-free. Activate hands-free speaking
17. R/Message. Put call on hold (inquiry), take call off hold or enter the message system.
18 Accessory connectors
19. Loudspeaker (rear side). For hands-free speaking function.

CallList icon
Marks an entry in the CallList. Three different call types are displayed:
<- Incoming call
-> Outgoing call
X Missed call
Signal strength
On when your phone is locked to the system. The bars indicate reception quality. Four bars indicate optimal reception.

Ringer off
Ringing signal muted or microphone off.

Key lock
Keys are locked.

Call
On when your phone is off hook and flashes during ringing.
Message
Message received.

Call info
New unanswered entry in the *MissedCalls* list.
Battery gauge
The battery cells are flashing sequentially when the battery is being charged and is on when charging is completed. Indicates the amount of talk and standby time left.
Note: *An alarm sounds when there is less than 15 minutes calling time left in the battery.*

Declaration of Conformity
Hereby, Ericsson Enterprise AB, S-131 89 Stockholm, declares that this telephone is in conformity with the essential requirements and other relevant provisions of the R&TTE directive 1999/5/EC.
Details to be found at: http://www.ericsson.com/sdoc

CE

Subject to alteration without notice

ERICSSON ≋