

This Quick Reference Guide includes short descriptions on how to use the basic functions. To learn more about all available functions, please see the related User Guide.

Free Seating

Answer Calls

Answer:

On another extension: Call ringing ext. 8

France: 4
Sweden: 6

Make Calls

Normal calls: Number

End call:

Individual External Line: ** * 0 * External line no. # External no.

II Extorn

Ericsson telephones:

Other analog telephones: ** ** **

Finland, Sweden: * * 0

Common abbreviated

Last External Number Redial:

number: Abbreviated no.

Individual abbreviated number: ** ** (0 - 9)

Finland: ** (1 - 9)
Sweden: (0 - 9) #

Dial By a Function Key: Head Office

Dialog 3105MW/3145/ 3145MW/3146

And any type of Analog Telephones for MD110 Communication System

Quick Reference Guide

The complete User Guide is available in electronic format for online viewing or printout on http://www.ericsson.com/enterprise

When You Receive a Busy Tone

Automatic Callback:

6 when called back)

France, Finland, Sweden: 5

Call Waiting: **5** (Stay "off hook")

France, Finland: 6
Sweden: 4

Intrusion (busy extension):

France, Sweden: 8

During Calls Monitoring:

onitoring:

Monitoring to handset:

Inquiry: R Call second party

Refer Back from Inquiry: 2

Sweden: R

Transfer:

** Call second party ** (Before or after answer)

Conference: R Call second party

(Wait for answer) **3** (To establish)

(To leave)

On Hold:

Note: Ext. no. = Extension number

(To resume on own

extension)

Mute (Ericsson analog telephones):

Call Forwarding

U.K.: * 2 #

Cancel: #21# 🖘

U.K.: #2#

Internal Follow-me

Answering pos. no. #

U.K.: *2 *

Cancel: #21# 🖘

U.K.: # 2 #

Redirect from ans. pos.: \star 2 1 \star Own ext. no.

X New answering pos. no.

~~~ U.K.: *2*

Cancel: #21 * Own ext.

no # ~~~ U.K.: #2*

â#22# ~

Ext. no. # (Wait for answer)

Absence Information

Cancel:

Cancel:

Cancel:

code * Date/Time # **

Ext. no. \star Absence code \star

Date/Time #

≈≒ #230×

Ext. no. #

Manual Message Waiting (MMW)

Answer MMW at own ext.:

Cancel: #31#

Order MMW to other ext.: ** ** * 31*

Ext. no. # ~~

Cancel: # 3 1 *

Ext. no. # 🦟

Group Facilities

Call Pick-up Group or

Common Bell Group: 8

Finland, Sweden: 0

Own ext. no. # 🚙

U.K.: ***2 ***

Re-enter group: #21#

U.K.: #2#

More Functions

Account Code: $\cancel{*}$ $\cancel{*}$ $\cancel{*}$ 6 1 $\cancel{*}$

Account code # External no.

Finland, Norway: *71*

General Cancellation: # 001#

Line access code Ӿ External

line no # 주

Cancel: #84#

Own ext. no.

DISA

Common auth. code: Call disa function ★72★

Authorization code #

External number

Individual auth. code: Call disa function $\pm 75 \pm$

Authorization code X
Own ext. no. #

External number

Do Not Disturb (DND): imes 27 #

Deactivate: #27#

