#51#

Programming

Individual abbreviated

number Erase one number

Erase all numbers

Function key on Dialog 3210

Change

Function key on Dialog 3211, 3212, 3213

Display Language*

★51★ (0-9) ★ No. #

★08★ Language code #

0 English

1 French

Note! In Finland: (1-9) #51 × (0-9) #

Number

or code

3 Spanish

4 Italian

During calls:

Program

Handset or loudspeaker volume

Tone Ringer Character

Select character for Dialog 3210

Volume Control

At idle or when ringing:

Tone ringer volume



Select character for Dialog 3211, 3212, 3213 Program (0-9)

Ringing Options Program permanent options for Dialog 3210

Program Access



Program permanent options for Dialog 3211, 3212, 3213

0 No ringing Repeated ringing

ringing

 \bigcirc \bigcirc (0-6)

2 Delayed repeated 3 Muted ringing

4 Delayed muted ringing 5 Immediate speech connection, key controlled

Access Program

6 Immediate speech

Temporary options** Silent ringing/Cancel Mute when ringing

Lamp Indications Rapidly flashing lamp

Slowly flashing lamp

Steady light

Light with short breaks



Incoming call

Ongoing call

is busy


The line is put on hold


The function is active or a supervised line



Adapting the Telephone

Tilting display on Dialog 3212 and 3213









Symbol Explanations



Lift the handset

(0-9)Diversion

Press a wanted digit on the keypad

David

Pre-programmed key Programmable key (name or function code)



Key below the display (Dialog 3213 only)



Replace the handset

Press the key

Press repeatedly the key as many times as shown

Extinguished lamp

Steady light

- Flashing lamp

Help for Telephone Type Identification









Ericsson Enterprise AB All rights reserved. For questions regarding the product, please contact your Ericsson Enterprise Certified Sales Partner. www.ericsson.se/enterprise

Dialog 3210, 3211, 3212, 3213

System Telephones for MD110

Quick Reference Guide





Dialog 3213

(without or with

Free Seating*

★ 11 ★ Individual ★ Ext. # Log on Log off #11#

Answer Calls

In general

Handsfree (Dialog 3211, 3212, 3213 only)

On another extension (Call pick-up)



Make Calls

Ordinary calls

Common abbreviated number

Individual abbreviated number

Dial by a function key

Last external number redial

Dial by name* (example: Eva) (Dialog 3213 only)

Dial by Number log* (Dialog 3213 only)

Dial number

extension

Dial abbreviated number

Note! In Finland: * (1-9) * * (0-9) In Sweden: (0-9) #

Note! In Finland: ** * 0

In Sweden: 6

Up/Down

Number log Next

During Connected Calls

Switch to loudspeaker (Dialog 3211, 3212, 3213 only)

Switch to handsfree (Dialog 3211, 3212, 3213 only)

Switch to monitoring via loudspeaker (Dialog 3210 only)

Switch to handset

Mute/cancel



Dial digits Note! In Finland: 1

On Hold

Dialling

Individual Resume call

Common

extension

Resume call - own ext. Resume call - another

Access

Access

Access

Call the extension where the call was put on hold

Note! In France: 4 In Sweden: 6

Note! In France: 4

8

Ø/Prog

Inquiry

Inquiry Ongoing conversation Call the 3rd party Inquiry Refer back or -` Access Return to first party

Transfer

Inquiry Call the Transfer (Press before or Ongoing conversation 3rd party

Conference

Inquiry Call the Ongoing conversation \bigcirc 3 (Press after answer) 3rd party

When Busy Tone or No Answer

Callback Cancel individual

Callback

Cancel all Callbacks

Activate Call waiting

★37★ Ext.. #

5 (At busy Wait on

#37#

Note! In France: 6 In Sweden: 4

Note! In Finland: In France: **5** In Sweden:

Call Forwarding

Diversion Diversion or * 21# Diversion Cancel or

Diversion at no answer **X 211 #** Cancel # 211 # Diversion at busy tone X 212 # Cancel #212#

Diversion bypass ★60★ Ext. #

Follow-me

Order from your **★21★** New ext. # own extension

Cancel #21#

Re-direct from **★21★** Own ext. **★** New ext. **#** answering extension

Cancel from # 21 * Own ext. # answering extension

Note! In U.K. for Follow-me: Dial 2 instead of 21!

External follow-me ¥ 22 # External code/No. #

#22# Cancel

Personal number* Activate or change profile

★10 ★ (1-5) #

Cancel #10#

General Cancellation

Cancel all activated #001# features

Voice Mail*

Entering your mailbox:

Dial Voice Follow recorded In general Mail number instructions Message Follow recorded New message received

Absence Information*

HHMM/ MMDD # **★23 ★** Cause: **Activate**

Cancel #23#

Account Code*

★61★ Account # External code & N New external call

Account # → ★61 ★ Ongoing external call

Note! In Finland and Norway: Dial 71 instead of 61

Authorization Code*

Common code

★72★ Common # External code & No. One single call

#73* Common code Unlock for some calls **★73★** Common # Lock after some calls

Individual code

Unlock your telephone #76 ★ Individual code Lock your telephone **★76★** Individual code

Call from own **★75★** Individual code telephone when locked

Assign another **★75★** Individual ★ Own # External code & No telephone

★74★ Old ★ New code # Change code

Note! ext. = extension No. *Optional